





Install the side rails on the (Optional) Install proper rings After assuring that your mount with provided screws. and long eye relief scope firearm is in good working (Recommended: AccuShot 1" order, you are ready to zero Scope 4-16x44, 30mm Scope 3-9x44, 6-24x56) on the top firing range. rail, and install Tactical Flashlight and Laser Sight on the side rails.

ADDITIONAL

SIDE RAILS

CORRECT INSTALLATION FRONT BAND

front end of the mount into

HOUSING

the Front Band housing.

Caution: Make sure firearm is not loaded. Remove magazine and examine chamber. Use safe handling procedures at all times.



Slide the UTG mount toward Place the Back Barrel Clip Pull the Operating Rod the Front Barrel Clip, and (with larger arc) onto the backward and hold the Rod to align the Sliding Grooves of barrel behind the Operating allow enough room for the the mount to accept the Front Rod Guide. Barrel Clip, and then push the

BARREL

Back Barrel Clip to move Twist the mount freely. outward and set enough distance away from the barrel to insert the right side of the Back Barrel Clip into the Sliding Groove of the mount.

TWIST MOUNT **OUTWARD TO ACCEPT RIGHT** SIDE OF THE **BACK BARREL** CLIP





Follow the manufacturer's manual to remove the buttfrom the firearm

BARREL

SIDE RAI



Turn the firearm upside down Position the Front Barrel Steel with gas tube above the Clip (with smaller arc) next to barrel. Place the receiver in a the Front Band between the vise with padded laws to gas tube and the barrel. And, hold the Clip next to the Front





COMBAT TACTICAL MNT-HGM14TR



the mount and the barrel, and Front and the Back Barrel around the barrel to make twist the mount inward Clips with the corresponding against the barrel for the screw holes on the mount, tightest fit to allow the left and turn the firearm upside side of the Back Barrel Clip to up - barrel above the gas be inserted into the other tube. Sliding Groove.

TWIST INWARD TO ALLOW FOR **BOTH SIDES OF BACK BARREL CLIP INTO SLIDING GROOVES**

SLIDING GROOVE

Close the distance between Align the screw holes of the Twist to adjust the mount sure that the mount is parallel to the bore centerline

> **PARALLEL TO** THE BORE CENTERLINE

Caution: Make sure firearm is not loaded. Remove magazine and examine chamber. Use safe handling procedures at all times.



